



OPHTHO-BURR® DIAMOND BURS

Warnings/Precautions	Remove burs from the handpiece before cleaning and sterilizing. Before sterilization, carefully inspect the burs under a microscope or magnifying glass for any irregularities or eccentricities. Discard any burs that show signs of damage or wear. Cold soak in glutaraldehyde, chlorine, or ammonium solutions, or dry heat sterilization is not recommended as damage may occur.			
Limitations	Discard any burs that show signs of damage or wear.			
INSTRUCTIONS				
Point of Use	Rinse immediately after use in distilled or demineralized water			
Containment and Transportation	It is recommended that burs are reprocessed as soon as is practical following use.			
Preparation for decontamination	Rinse immediately after use in distilled or demineralized water			
Cleaning: Automated	Remove instruments and equipment from any sterilization trays before placing into washer baskets. Orient devices following recommendations of washer/disinfector manufacturers. Use alkaline or neutral pH detergent recommended by washer/disinfector or detergent manufacturers. These products have been validated for effective cleaning using an automatic washer/disinfector cycle consisting of a minimum 44 minutes total time, including a pre-wash, main wash & rinse, and thermal rinse. The thermal rinse shall be at least 10 minutes long at a minimum temperature of 60°C.			
Cleaning: Manual	Soak in lukewarm (less than 43°C), mild (pH 7.0 - 8.5), enzymatic detergent and deionized water for a minimum of 2 minutes, then clean ultrasonically in a lukewarm (less than 43°C), mild (pH 7.0 - 8.5), detergent and deionized water for at least 30 seconds. Rinse thoroughly with deionized water and wipe dry. Note: When using an ultrasonic cleaner or a spray washing machine, follow the manufacturer's recommendations, particularly with regard to articulated instruments and positioning of instruments.			
Disinfection	No particular requirements			
Packaging	No particular requirements			
Sterilization (Temperatures are minimum required, times are minimum required)	Cycle:	Gravity	Pre-Vac	
	Temperature:	121°C	134°C	
	Time:	30 min	3 min	
	Drying: 8 min or until visibly dry			
	EtO: Not validated		STERRAD Sterilization: Not validated	
Maintenance, Inspection and Testing	After cleaning and sterilization, verify functionality prior to re-use. Discard any burs that show signs of damage or wear.			
Storage	No particular requirements			
Additional Information	None			

Note: The instructions provided above have been validated by the manufacturer as being CAPABLE of preparing the product for re-use. It remains the responsibility of the processor to ensure that the reprocessing as actually performed using equipment, materials and personnel in the reprocessing facility achieve the desired result. This normally requires validation and routine monitoring of the process.